


direction of rotation can only be reversed by hand lever „M“

direction of rotation can be reversed manually or pneumatically „MP“






X
control **M**

X
control **MP**

Z
control **M/MP**

hand lever right / activation X2 - anti-clockwise rotation



hand lever left / activation X1 - clockwise rotation

